




Door Handing Chart



The “handing” of a door refers to the direction that the door swings. It is important to know the correct handing of your opening when ordering Doors, Frames, Exit Devices and other hardware. The hand of the door is determined by the secure side (the side which you initially unlock and enter) of the door.

A Left Handed Door has hinges on the left and opens inward. Secure side is the “Push” side of door.

A Right Handed Door has hinges on the right and opens inward. Secure side is the “Push” side of door.

A Left Handed Reverse Door has hinges on the left and opens outward. Secure side is the “Pull” side of door.

A Right Handed Reverse Door has hinges on the right and opens outward. Secure side is the “Pull” side of door.

Double doors usually have an active leaf and inactive leaf. Again, from the secure side of the opening.

Double Egress Doors go in opposite directions. Usually both doors leaves are active. (LHR/LHR or RHR/RHR).

Whenever there is an exit device on your opening. It is a reverse bevel door. (RHR, LHR)